



CORROSION PROTECTION

< REMOVAL AND INSTALLATION >



A. Nozzle insert hole

 : Anti-corrosive wax coated portions

Undercoating

INFOID:000000001348338

The underside of the floor and wheelhouse are undercoated to prevent rust, vibration, noise and stone chipping. Therefore, when such a panel is replaced or repaired, apply undercoating to that part. Use an undercoating which is rust preventive, soundproof, vibration-proof, shock-resistant, adhesive, and durable.

Precautions in Undercoating

1. Do not apply undercoating to any place unless specified (such as the areas above the muffler and three way catalyst which are subjected to heat).