




REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >



Unit: mm (in)



JSKIA0147GB

← : Vehicle front

View E, F: Left side member view

Front Pillar

Work after hoodledge reinforcement has been removed.
Remove the inner front pillar reinforcement for easier butt welding of the side dash.

A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P