


REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

- Insert nozzle into hole near fill area and fill foam material or fill in enough to close gap with the service part.



- 1. Urethane foam
- A. Nozzle insert hole

⇐ : Vehicle front

- 2. Fill procedures before installation of service part.
 - Remove foam material remaining on vehicle side.
 - Clean area in which foam was removed.
 - Fill foam material on wheelhouse outer side.

- 1. Urethane foam
- A. Fill while avoiding flange area

⇐ : Vehicle front


NOTE:

Fill in enough to close gap with service part while avoiding flange area.

- Install service part.

NOTE:

Refer to label for information on working times.



Hoodledge

INFOID:000000001348351

Remove the hoodledge reinforcement gusset (reusable).