




# BODY COMPONENT PARTS

## < REMOVAL AND INSTALLATION >

10. Inner side roof rail (RH & LH)	11. Inner center pillar (RH & LH)	12. Outer sill (RH & LH)	A
13. Inner rear pillar (RH & LH)	14. Upper rear pillar reinforcement (RH & LH)	15. Back pillar reinforcement assembly (RH & LH)	
16. Rear roof rail brace (RH & LH)	17. Inner rear side brace (RH & LH)	18. Lower inner rear pillar (RH & LH)	
19. Outer rear wheelhouse (RH & LH)	20. Outer rear wheelhouse extension (RH & LH)	21. Inner rear wheelhouse (RH & LH)	B
22. Roof	23. Center roof rack bracket (RH & LH)	24. Roof rack bracket assembly (RH & LH)	C
25. Front roof rail	26. Roof bow No. 1	27. Roof bow No. 2	
28. Roof bow No. 3	29. Roof bow No. 4	30. Roof bow No. 5	
31. Rear roof bow	32. Rear roof rail	33. Roof reinforcement assembly	D
34. Rear pillar bracket (RH & LH)	35. Rear fender assembly (RH & LH)	36. Rear combination lamp base (RH & LH)	
37. Rear fender corner (RH & LH)	38. Fuel filler lid	39. Rear end crossmember assembly	
40. Rear side bumper bracket	41. Rear panel assembly	42. Upper rear bumper retainer	E
43. Front door assembly (RH & LH)	44. Outer front door panel (RH & LH)	45. Rear door assembly (RH & LH)	
46. Outer rear door panel (RH & LH)	47. Back door	48. Inner center front bumper reinforcement	
49. Rear bumper stay	50. Inner center rear bumper reinforcement		F
A. Standard roof	B. With sunroof	C. Standard roof rail	G
D. With hyper roof rail	E. RH side		
 : Both sided anti-corrosive precoated steel portions			
 : High strength steel (HSS) portions			H
 : Both sided anti-corrosive steel and HSS portions			I

BRM

L

M

N

O

P