

SECTION

BRM

BODY REPAIR

A

B

C

CONTENTS

E

HOW TO USE THIS MANUAL	2	Description	18	F
FOREWORD	2	BODY CONSTRUCTION	21	
Foreword	2	Body Construction	21	G
FEATURES OF NEW MODEL	3	BODY ALIGNMENT	23	
GENERAL INFORMATION	3	Body Center Marks	23	
Identification Number	3	Panel Parts Matching Marks	24	H
Identification Plate	4	Description	25	
BODY EXTERIOR PAINT COLOR	5	Engine Compartment	25	
Body Exterior Paint Color	5	Underbody	28	I
PRECAUTION	7	Passenger Compartment	30	
HANDLING PRECAUTIONS	7	Rear Body	32	
Precautions For Plastics	7	REPAIRING HIGH STRENGTH STEEL	34	J
REMOVAL AND INSTALLATION	10	High Strength Steel (HSS)	34	
BODY COMPONENT PARTS	10	REPLACEMENT OPERATIONS	37	
Underbody Component Parts	10	Description	37	
Body Component Parts	12	Hoodledge	40	
CORROSION PROTECTION	14	Hoodledge (Partial Replacement)	42	
Description	14	Front Side Member	44	L
Anti-corrosive Wax	14	Front Side Member (Partial Replacement)	48	
Undercoating	15	Front Pillar	49	
Stone Guard Coat	16	Center Pillar	52	M
BODY SEALING	18	Outer Sill	56	
		Rear Fender	57	
		Rear Panel	60	N
		Rear End Crossmember	60	
		Rear Floor Rear	62	
		Rear Side Member Extension	63	O

P